Tone Control
Press to access Bass, Treble, Balance and Fader control.
Press –♩+, –𝄾+ to decrease/increase bass and treble.
Press <B> or ∧F∨ to change balance and fader.

Source Selector
Double click (push twice, fast) then press repeatedly until desired source, Radio, Cassette or CD appears. Press only once to return to privious source.

Function Button
Press to access Autostore, Manual Tuning, Numeric Frequency Selection and CD menu.

Cassette Eject Button

AM/FM Selector
Press to select desired band.

Program Indicator

ON/OFF
Press to turn radio on or off.

Cassette Slot
Insert Cassette to play

Traffic Programm Button
Press to find the next RDS coded FM station with traffic program

Source and Preset Indicator

Volume Control
Press –/+ for decrease/increase

Signal Seek Switch
Seek: Press ∧ or ∨ to select next or previous station on radio, title on cassette or CD.
Scan: Press and hold ∧ for two seconds to scan radio stations or music titles on cassette or CD.

Traffic Program Indicator

Multifunction Keys
Radio: To set 10 AM and 10 FM stations tune to desired station, press and hold for two seconds. In function mode also used for Autostore, Manual Tuning and Numeric Frequency Selection.
Cassette: Select 1 or 2 for track change.
<< or >> for fast rewind or forward (to cancel press again), press DD to select Dolby B or C and use SB to skip blank tape.
CD-Changer: Press number 1 through 6 to select any one of the CD's in the magazine.

Removable Display
For added protection against theft remove the display unit by pressing the button to the right of the signal seek switch. To operate radio again push display into its place.

See Main Operation Guide in your Glove Box for many more features.

* CD Changer functions require optional Porsche CD Changer.